# **Hydraulic Elevator Shaft Dimensions**

# For Manual Doors Elevator

Passenger Capacity	Clear Opening (C)	Required Shaft Sizes		
		Manual Swing + IFG/Collapsible Door		
		Width (W)	Depth (W)	
3 to 6	700	1000	1200	
	800	1300	1100	

### **For Auto Doors Elevator**

Passenger Capacity	Clear Opening	Required Shaft Sizes				
		Side Opening Auto Door		Centre Opening Auto Door		
		Width (W)	Depth (W)	Width (W)	Depth (W)	
4 to 6	700	1300	1200	1500	1200	
	800	1300	1100	1800	1400	

#### NOTE:

- 1. All dimensions are in mm.
- 2. Above dimensions are inner-inner dimensions and applicable when there is lift well, or lift shaft present.
- 3. If lift shaft is not present, then lift can also be installed externally by erecting structure.
- 4. For structure, the 150 mm will added in both above dimensions.

### For Reliable Lifts India Pvt. Ltd.

Rajwade Commercial Complex, Office No. 09, 3rd Floor, Near Podar International School,

Old Katraj Highway, Ambegaon Bk., Pune – 411 046.

Ph. No.: 020 - 65212140 Helpline: +91 9595 4169 16

E-Mail ID: reliablelifts2012@gmail.com / info@reliablelifts.in Web: www.reliablelifts.in

